

(t)RFU-2400

User Manual

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2016 by ICP DAS. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Technical Support

If you have any problems, feel free to contact us via email at service@icpdas.com

Table of Contents

1	Introduction.....	1
2	Hardware Information.....	5
2.1	Specifications	5
2.2	Block Diagram.....	6
2.3	Pin Assignments	6
2.4	Dimensions (Units:mm).....	8
3	Setting up the (t)RFU-2400.....	10
3.1	Overview of the configuration Parameters.....	10
3.2	Start Configuration.....	17
3.2.1	Hardware Configuration	17
3.2.2	Software Configuration (Advanced)	21
4	Examples.....	23
4.1	Configuration Examples.....	23
4.2	Application Examples.....	27
5	Communication Verification.....	30
6	Accessories.....	33
6.1	High-gain Antenna.....	33
6.2	Extension Cable.....	36

What's in the shipping package?

The shipping package includes the following items:



① RFU-2400 & ANT-124-05

① tRFU-2400



② CA-0910

③ Quick Start

④ CD

If any of these items are missing or damaged, please contact your local distributor for more information. Save the shipping materials and cartons in case you need to ship the module in the future.

More Information

■ Documentation:

All documentation related to the RF series modems can be found on the companion CD at:

CD: \Napdos\RF_Modem\Document

Or can be downloaded from:

http://ftp.icpdas.com/pub/cd/usbcd/napdos/rf_modem/document

■ Software Configuration Utility

Utility software for the ZT Series of devices can be found on the companion CD at:

CD: \Napdos\RF_Modem\Utility

Or can be downloaded from:

http://ftp.icpdas.com/pub/cd/usbcd/napdos/rf_modem/utility

1 *Introduction*

Main Function Description

The RFU-2400/tRFU-2400 is hereinafter referred to as (t)RFU-2400. The (t)RFU-2400 is a 2.4 GHz radio frequency modem that also provides RS-232, RS-485 and RS-422 port interfaces. The (t)RFU-2400 is designed to act as a wireless bridge that converts a signal between serial and wireless formats, and is useful for applications where it is inconvenient to install physical wiring. The (t)RFU-2400 makes it easy to establish a low cost environment for data acquisition and control applications between a host and a range of remote sensors via wireless communication.

The (t)RFU-2400 can be widely used in IoT applications, including industrial control, embedded sensor control, and medical data collection, as well as for other equipment that requires short-range wireless transfer of data at relatively low transfer rates.

Features – Wireless Connections (IEEE 802.15.4)

The (t)RFU-2400 is a spread spectrum radio frequency (RF) modem based on the IEEE 802.15.4 standard. The specifications relating to RF technology are implemented in the OSI layers, as described in the following.

The IEEE 802.15.4 standard defines the basic functions of the transmission radio frequency for the physical (PHY) layer, which operates on the ISM bands using a transmission frequency range of between 2405 and 2480 MHz that is separated into 5 MHz segments, thereby providing 16 channels. Direct-sequence spread spectrum (DSSS) RF technology is also implemented in the PHY layer, providing advantages such as stable, high quality wireless communication, resistance to eavesdropping or interception, and anti-jamming capabilities. Modulation based on OQPSK (offset quadrature phase-shift keying) with a Half-sine Chip Shaping filter is also supported in order to provide high-quality spectral efficiency and anti-nonlinear capabilities.

The IEEE 802.15.4 standard also defines a number of important networking functions related to the MAC layer, including the addressable ID numbers, wireless channel access, and communication coordination. In addition, 16 logical groups are provided that can be used to select the individual RF channels. Two operating

modes are also supported, including Peer-to-Peer (P2P) mode, where the distinguishing feature is that it allows full-duplex communication, and Broadcast mode, which allows half-duplex functionality in multi-point communication.

Features – Wired Connections (RS-232/RS-485)

The (t)RFU-2400 module can be connected using either the RS-232 or RS-485 serial interface. Four data formats are supported, N81, O81, E81 and N82, and the Baud Rate can be selected in the range of between 2400 and 115200 bps. When the (t)RFU-2400 is set to operate in P2P Mode, a Baud Rate of up to 57600 bps can be configured for full-duplex communication. When the (t)RFU-2400 is set to operate in Broadcast Mode, a Baud Rate of up to 115200 bps can be configured for half-duplex communication.

For normal operations, the (t)RFU-2400 is typically configured via user-friendly external DIP and Rotary Switches, making it easy to configure the device. In addition, ICP DAS provides a Windows-compatible GUI configuration utility that can be used to configure the various communication parameters via an RS-232 / RS-485 / RS-422 connection. For example, the configuration utility can be used to increase the transmission power when a line of sight communication range that is greater than the default of 180/700 meters is required.


2 Hardware Information

2.1 Specifications


Model Name		RFU-2400	tRFU-2400	
Wireless				
Wireless	Modulation	OQPSK (Offset Quadrature Phase-shift Keying)		
	Spread Spectrum	DSSS (Direct-Sequence Spread Spectrum)		
	Channels	16		
	Sensitivity	-97 dBm	-97 dBm	
	Transmission Power	11 dBm (Default) 19 dBm (Max.)	11 dBm (Default) 17 dBm (Max.)	
	Antenna	5 dBi Omnidirectional Antenna	3 dBi PCB Antenna	
	Transmission Range	700 m (Typical)	180 m (Typical)	
Hardware				
COM0	COM 0	RS-232	TxD, RxD and GND	
		RS-485	DATA+, DATA-; Internal ASIC Self-tuner; Non-isolated	
		RS-422	N/A TxD+, TxD-, RxD+, RxD	
	Baud Rate	Full-duplex	2400 to 57600 bps	
		Half-duplex	2400 to 115200 bps	
	Data Format	N81, O81, E81, N82		
Buffer	2560 Bytes			
LED Indicators	Green	RF TxD	Rx/Tx	
	Yellow	RF RxD	Power State	
	Red	Power Status	N/A	
Power	EMS Protection	ESD, Surge, EFT and Hi-Pot		
	Required Supply Voltage	+10 VDC ~ +30 VDC		
	Power Consumption	1 W (Max.)	0.4 W (Max.)	
Mechanical	Casing	Plastic		
	Flammability	UL 94V-0 materials		
	Dimensions (W × L × H)	84mm x 108mm x 33 mm	52 mm x 95 mm x 27 mm	
	Installation	DIN-Rail		
Environmental	Operating Temperature	-25 to +75°C		
	Storage Temperature	-40 to +80°C		
	Relative Humidity	0 to 90% RH, Non-condensing		

2.2 Block Diagram

- RFU-2400




- RFU-2400




2.3 Pin Assignments

- RFU-2400




- tRFU-2400




2.4 Dimensions (Units: mm)

- RFU-2400



- tRFU-2400



3 *Configuring the (t)RFU-2400*

3.1 Overview of the Configuration Parameters

(1) The RF Channel:

The “RF Channel” parameter specifies the actual radio frequency channel to be used by the (t)RFU-2400 module, and must be set to the same channel if the module is in the same communication group as other (t)RFU-2400 modules. For more details relating to communication groups, refer to the “Group ID” section below. For more details regarding the configuration of the RF channel via hardware, refer to [Section 3.2.1 "Hardware Configuration \(RF Channel\)"](#) below.


Channel Selection:

As the 2.4 GHz ISM band is a globally available frequency range, a significant number of devices operate within this band, which may, of course, generate a high possibility of signal interference. Consequently, the selection of a suitable channel is an extremely important consideration when implementing an (t)RFU-2400 network. The most ideal solution would be to select an RF channel that is not occupied by other devices, as this will improve the efficiency of wireless transmission.

Channel Selection Method:

The best approach when attempting to identify a suitable RF channel for use by the (t)RFU-2400 module is to employ a WiFi Analyzer application on a smartphone or other WiFi enabled device to scan for WLAN channels that are currently occupied by other devices within range of the (t)RFU-2400 module, thereby assisting in the detection of wireless signals in the vicinity and allowing an analysis of the WLAN to be performed.

For example, as indicated in the diagram below, there are WLAN users currently occupying channels 1, 6 and 11.



As can be seen in the diagram, ZigBee channels 4, 9, E and F do not overlap the WiFi channels, so it is recommended that one of these channels be used.

The chart shown below provides an overview of the wireless channels that are appropriate for the (t)RFU-2400/ZigBee (IEEE 802.15.4) specifications in comparison to the WLAN (IEEE 802.11b/g) standard, and illustrates the relationship between the WiFi and the ZigBee channels. This can be used to give an indication of the most suitable channel that can be selected for use by the (t)RFU-2400.

(2) Group ID

The “**Group ID**” parameter specifies the logical group identity for (t)RFU-2400 devices, and each (t)RFU-2400 module must be set to the same value if it is in the same group as other modules. For more details regarding the configuration of the Group ID via hardware, refer to [Section 3.2.1 “Hardware Configuration \(Group ID\)”](#) below.

※ Reminder: When attempting to differentiate between different communication groups, the first priority is to adjust the RF Channel. However, if too many (t)RFU-2400 groups occupy all the RF channels, the Group ID parameter is the second priority to be configured when creating a new group.

(3) Application Mode

Two wireless communication modes can be configured, Peer-to-Peer (P2P) mode and Broadcast mode, as described below. For more details regarding the configuration of the Application Mode via hardware, refer to [Section 3.2.1 “Hardware Configuration \(Application Mode\)”](#) below.

Peer-to-Peer (P2P) Mode

In Peer-to-Peer (P2P) mode, full-duplex (TDD, time-division duplexing) communication is supported between the two nodes, with the limitation that only two (t)RFU-2400 devices are allowed to be included in a single communication group.

Broadcast Mode

In Broadcast mode, data transmission is performed via a broadcast frame. Broadcast mode is suitable for multi-point communication. Although there are no limitations to the number of (t)RFU-2400 devices that can be included in a single



communication group, only half-duplex communication supported. Since there is the possibility that data collision can occur during wireless transmission, a Master-Slave (Question-Response) architecture is recommended.

(4) Data Format & Baud Rate

The specific “**Data Format**” and “**Baud Rate**” values that need to be used will entirely depend on how the serial port has been configured. For more details regarding the configuration of the Data Format and Baud Rate via hardware, refer to [Section 3.2.1 “Hardware Configuration \(Data Format/Baud Rate\)”](#) below.

※ Note

The RS-232/RS-485 connections to each (t)RFU-2400 device are independent, so the Data Format settings for each connection are also independent, as illustrated in the diagrams below.



(5) Configuration Mode

Two configuration modes can be used, as described below.

Hardware Configuration (HW_Cfg)

Typically, each (t)RFU-2400 module will be configured using the device hardware, based on the positions of both the Rotary Switch and the DIP Switches, and this normally applies in the majority of cases. For more details regarding the configuration of the Configuration Mode via hardware, refer to [Section 3.2.1 "Hardware Configuration \(Configuration Mode\)"](#) below.

Software Configuration (SW_Cfg)

As mentioned above, each (t)RFU-2400 module will generally be configured using the device hardware. However, software configuration can be performed in situations where advanced configuration settings are required, such as when adjusting the RF Power. See the RF Power section below for more details. For more information regarding [Software Configuration, refer to Section 3.2.2](#) below.

(6) RF Power (Advanced Configuration)

The **"RF Power"** parameter specifies the wireless transmit power value, and is used to adjust the transmit power via the configuration utility. If the transmit power is too low to be able to communicate with a remote device, increasing it will improve the quality of the communication so that it becomes more stable.

Any adjustment of the RF Power should be performed in Software Configuration mode (SW_Cfg), although the RF Power value affects the status of both the

Hardware Configuration (HW_Cfg) and the Software Configuration (SW_Cfg).

For more details regarding the configuration of the RF channel, refer to [Section 3.2.2 "Software Configuration"](#) below.


※ *The adjustment of this parameter is based purely on individual requirements, and ICP DAS cannot guarantee compliance with CE/FCC certification if this parameter is adjusted, nor is any liability assumed if the adjustment parameters are derived from the RF Power.*

3.2 Beginning Configuration

As described previously, two methods are available for configuring the (t)RFU-2400 device. In most cases, hardware configuration should be all that is necessary to configure the device. However, in certain circumstances where advanced requirements are necessary, the (t)RFU-2400 can be configured using software. The following topics describe the process used for configuring the device via either hardware or software.

3.2.1 Hardware Configuration

The configuration for the (t)RFU-2400 module can be adjusted using a combination of the external Rotary Switches and the DIP switches. Note that the (t)RFU-2400 device should only be rebooted once the configuration is complete.



(1) [RF Channel:](#)

Rotary Switch 1 is used to specify the radio frequency (RF) channel for the module. If the module is in the same group as other (t)RFU-2400 modules, the RF Channel value must be set to the same channel as the other modules in the same group. Refer to the "Group ID" section below for more details of how to configure group identities.

	Frequency (MHz)	RFU-2400		tRFU-2400	
		HW_Cfg	SW_Cfg	HW_Cfg	SW_Cfg
0	2405	RSW=0	✓ Default	RSW=0	✓ Default
1	2410	RSW=1	✓	RSW=1	✓
.....	✓	✓
F	2480	RSW=F	✓	RSW=F	✓

(2) [Group ID:](#)

Rotary Switch 2 is used to specify the group identity for the network, and the Group ID for each device in the same network must be set to the same value. Refer to the table below for details.

Group ID	RFU-2400		tRFU-2400	
	HW_Cfg	SW_Cfg	HW_Cfg	SW_Cfg
0x0000	RSW=0	✓ Default	✓ Fixed	✓ Default
0x0001	RSW=1	✓	×	✓
.....	✓	×	✓
0x000F	RSW=F	✓	×	✓

(3) [Application Mode:](#)

The Application Mode to be used by the (t)RFU-2400 device is configured using DIP Switches 1 and 2. Refer to the following diagrams for details of which DIP Switch combination is used to configure a specific Application Mode.

App. Mode	RFU-2400			tRFU-2400		
	HW_Cfg		SW_Cfg	HW_Cfg		SW_Cfg
	DIP 1	DIP 2		DIP 1	DIP 2	
Broadcast	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	✓ Default	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	✓ Default
P2P/Master	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	✓	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	✓
P2P/Slave	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	✓	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	✓

(4) [Data Format:](#)

The Data Format for the (t)RFU-2400 device is configured using DIP Switches 3 and 4. Refer to the following diagrams for details of which DIP Switch combination is used to configure a specific Data Format.

Data Format	RFU-2400			tRFU-2400	
	HW_Cfg		SW_Cfg	HW_Cfg	SW_Cfg
	DIP 3	DIP 4			
N,8,1	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	✓ Default	✓ Fixed	✓ Default
O,8,1	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	✓	×	✓
E,8,1	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	✓	×	✓
N,8,2	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	✓	×	✓

(5) [Baud Rate:](#)

The Baud Rate for the (t)RFU-2400 device can be set in the range of 2400 to 115200 bps, and can be configured using DIP Switches 5, 6 and 7. Refer to the following diagrams for details of which DIP Switch combination is used to configure a specific Baud Rate.

Baud Rate	RFU-2400			tRFU-2400		
	HW_Cfg			SW_Cfg	HW_Cfg	SW_Cfg
	DIP 5	DIP 6	DIP 7			
115200	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	✓ Default	×	✓ Default
57600	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	✓	×	✓
38400	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	✓	×	✓
19200	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	✓	×	✓
9600	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	✓	✓ Fixed	✓
4800	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	✓	×	✓
2400	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	✓	×	✓
Debug	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	✓	×	✓

※ Note:

If DIP Switches 5, 6 and 7 are each moved to the ON position, the (t)RFU-2400 device will be set to Debug Mode, which is used to perform wireless communication testing.

(6) [Configuration Mode:](#)

	RFU-2400	tRFU-2400	
	DIP 8	DIP 1	DIP 2
Hardware Configuration Mode (HW_Cfg)	<input type="checkbox"/> OFF	other positions	
Software Configuration Mode (SW_Cfg)	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON

- **Hardware Configuration Mode (HW_Cfg)**

Typically, each (t)RFU-2400 module will be configured using the device hardware, based on the positions of both the Rotary Switch and the DIP Switches, and this normally applies in the majority of cases.

- **Software Configuration Mode (SW_Cfg)**

As mentioned above, each (t)RFU-2400 module will generally be configured using the device hardware. However, software configuration can be performed in situations where advanced configuration settings are required, such as when adjusting the RF Power.


3.2.2 Software Configuration (Advanced)

The following describes the process used for configuring the device via the software utility. More details relating to the Software Utility for the ZT Series of devices, including installation and usage instructions, can be found in the \Napdos\ZigBee\ZT_Series\Utility folder on the companion CD, or can be downloaded from:


http://ftp.icpdas.com/pub/cd/usbcd/napdos/rf_modem/utility

Step 1. Move the INIT DIP Switch on the (t)RFU-2400 to the ON position and then reboot the device.

Step 2. Start the configuration utility for the (t)RFU-2400 device and then select the relevant COM port to establish a connection with the device.



Step 3. Click the “Read Configuration” button to display the current configuration for the (t)RFU-2400 device. Enter the required configuration details and then click the “Start Configuration” button to save the new parameters for the device.



Step 4. Once the configuration update has been completed, turn off the power to the machine, move the INIT switch to off position, turn on the power again to reboot the machine.

<Reminder> Configuration Mode

- In order to configure the device via the software utility, move DIP Switch 8 to the ON position. (RFU-2400)
- If only the [RF Power](#) has been changed, there is no need to move DIP Switch 8 to the ON position and it can remain in the OFF position. (RFU-2400)

	RFU-2400	tRFU-2400	
	DIP 8	DIP 1	DIP 2
Hardware Configuration Mode (HW_Cfg)	<input type="checkbox"/> OFF	other positions	
Software Configuration Mode (SW_Cfg)	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> ON

4 Examples

4.1 Configuration Examples

(1) P2P/Full-duplex

- The configuration illustrated below is suitable for peer-to-peer applications and full-duplex communication. The channel access method for full-duplex communication is based on time-division duplexing, which means that both the P2P_Master and the P2P_Slave are able to transmit data at any time, and then receive the data in sequence.
- A transmission based on RS-232 is a typical example of full-duplex communication, and can be used in scenarios where the communication range between two PLC devices needs to be extended.



- Example:

The following is an example of the configuration that can be used to implement a peer-to-peer communication application illustrated above. In this case, attention should be paid to two particular settings, i.e., the Application Mode must be set to P2P Mode and the Baud Rate must be set to a maximum of 57,600 bps. All other settings are can be configured depending on specific customer requirements.

✓ RFU-2400


Item	Switch	Controller Side		I/O Side	
RF Channel	Rotary (L)	E	2475 MHz	E	2475 MHz
Group ID	Rotary (R)	0	Network = 0x0000	0	Network = 0x0000
App. Mode	DIP_1	<input type="checkbox"/>	P2P_Master (Full-duplex)	<input checked="" type="checkbox"/>	P2P_Slave (Full-duplex)
	DIP_2	<input checked="" type="checkbox"/>		<input type="checkbox"/>	
Data Format	DIP_3	<input type="checkbox"/>	N,8,1	<input type="checkbox"/>	O,8,1
	DIP_4	<input type="checkbox"/>		<input checked="" type="checkbox"/>	
Baud Rate	DIP_5	<input type="checkbox"/>	57600 bps	<input type="checkbox"/>	57600 bps
	DIP_6	<input type="checkbox"/>		<input type="checkbox"/>	
	DIP_7	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
Config. Mode	DIP_8	<input type="checkbox"/>	Hardware Config.	<input type="checkbox"/>	Hardware Config.
Note		Off : <input type="checkbox"/> On : <input checked="" type="checkbox"/>			

✓ tRFU-2400

Item	Switch	Controller Side		I/O Side	
RF Channel	Rotary	E	2475 MHz	E	2475 MHz
Group ID	---	---	0x0000	---	0x0000
App. Mode	DIP_1	<input type="checkbox"/>	P2P_Master (Full-duplex)	<input checked="" type="checkbox"/>	P2P_Slave (Full-duplex)
	DIP_2	<input checked="" type="checkbox"/>		<input type="checkbox"/>	
Data Format	---	---	N,8,1	---	N,8,1
Baud Rate	---	---	9600 bps	---	9600 bps
Config. Mode	---	---	Hardware Config.	---	Hardware Config.
Note		Off : <input type="checkbox"/> On : <input checked="" type="checkbox"/>			

(2) Broadcast/Half-duplex Mode

- The configuration illustrated below is suitable for multi-point applications and half-duplex communication. Data can be transmitted from any (t)RFU-2400 device within the network to each (t)RFU-2400 device within the same network on a wireless carrier, but not at the same time.
- Master/Slave communication is the typical architecture model used in Broadcast/Half-duplex mode. For example, in this scenario, the controller polls the remote devices to acquire data using the DCON/Modbus protocol, which is the typical Master/Slave architecture when using broadcast frame and half-duplex communication.



- Example:

The following is an example of the configuration that can be used to implement the multi-point communication application illustrated above. In this case, the Application Mode should be set to Broadcast Mode, but the other settings can be configured depending on specific customer requirements.

✓ tRFU-2400

Switch	Item	Controller Side		I/O Side	
RF Channel	Rotary (L)	E	2475 MHz	E	2475 MHz
Group ID	Rotary (R)	0	Network = 0x0000	0	Network = 0x0000
App. Mode	DIP_1	<input type="checkbox"/>	Broadcast (half-duplex)	<input type="checkbox"/>	Broadcast (half-duplex)
	DIP_2	<input type="checkbox"/>		<input type="checkbox"/>	
Data Format	DIP_3	<input type="checkbox"/>	N,8,1	<input type="checkbox"/>	N,8,1
	DIP_4	<input type="checkbox"/>		<input type="checkbox"/>	
Baud Rate	DIP_5	<input type="checkbox"/>	115200 bps	<input type="checkbox"/>	115200 bps
	DIP_6	<input type="checkbox"/>		<input type="checkbox"/>	
	DIP_7	<input type="checkbox"/>		<input type="checkbox"/>	
Config. Mode	DIP_8	<input type="checkbox"/>	Hardware Config.	<input type="checkbox"/>	Hardware Config.
Note		Off : <input type="checkbox"/> On : <input checked="" type="checkbox"/>			

✓ tRFU-2400

Item	Switch	Controller Side		I/O Side	
RF Channel	Rotary	---	Software Config.	E	Software Config.
Group ID	---	---	Software Config.	---	Software Config.
App. Mode	DIP_1	<input checked="" type="checkbox"/>	SW_Config. Mode	<input checked="" type="checkbox"/>	SW_Config. Mode
	DIP_2	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
Data Format	---	---	Software Config.	---	Software Config.
Baud Rate	---	---	Software Config.	---	Software Config.
Config. Mode	---	---	Software Config.	---	Software Config.
Note		Off : <input type="checkbox"/> On : <input checked="" type="checkbox"/>			


4.2 Application Examples

(1) Multi-point Communication

In this example, several (t)RFU-2400 modules act as wireless converters that are responsible for broadcasting data to multiple remote devices in Broadcast (half-duplex) mode. A PLC is wirelessly connected to one or more (t)RFU-2400 devices, and the remote I/O modules are each connected to additional (t)RFU-2400 devices via the serial RS-485 port. The (t)RFU-2400 devices then communicate wirelessly to enable data transfer between the PLC and the I/O modules.

✓ Broadcast/Half-duplex

As communication within a multi-point architecture must be performed in half-duplex mode, Broadcast/Half-duplex mode is the only method of conducting the data collection.




(2) Communication between two remote locations

a. In this example, the (t)RFU-2400 module is acting as a bridge between the controller and the remote I/O device in either Broadcast (half-duplex) or P2P (full-duplex) mode. A controller is connected to an (t)RFU-2400 device via the serial RS-232 port, and the remote I/O module is connected to a second (t)RFU-2400 device via the serial RS-485 port. The (t)RFU-2400 devices then communicate wirelessly to enable data transfer between the controller and the I/O module.

✓ Broadcast/Half-duplex


As the RS-485 interface is only allowed for half-duplex communication, Broadcast/Half-duplex is the only method of conducting the data collection.



b. In this example, the (t)RFU-2400 module is acting as a bridge between two controller devices in P2P (full-duplex) mode. Both controllers are connected to an (t)RFU-2400 device via the serial RS-232 port. The (t)RFU-2400 devices then communicate wirelessly to enable data transfer between the two PLC devices.

✓ Broadcast/Half-duplex & P2P/Full-duplex

As the RS-232 interface allows communication to be performed in either half- or full-duplex mode, both Broadcast Mode and P2P Mode can be used to conduct data collection. The only limitation is that the application mode for both (t)RFU-2400 devices must be the same.




5 Communication Verification

The RFU-2400 can be used once the configuration has been completed. However, if a failure occurs in the wireless communication, use the following procedure to analyze the status of the communication in order to determine the source of the problem.

(1) Configure the RFU-2400 device

Before beginning an analysis of the communication status, first set both the RFU-2400 device that is acting as the monitoring target and the device connected to the Host PC to Debug Mode using the procedure described below.


- Move the INIT DIP Switch on both RFU-2400 devices to the OFF position
- Move DIP Switches 5, 6 and 7 on both RFU-2400 devices to the ON position and reboot the devices.



(2) Start the configuration utility for the RFU-2400

To begin testing the communication status, open the configuration utility by double clicking the icon on the desktop and then follow the procedure described below.

- In the Configuration Utility, click the **COM Port Selection** option and then select the relevant COM Port to be used to connect to the RFU-2400 device.
- Click the **Communication Test** option to start the communication test.



(3) View the test results for the Received Signal Strength Indicator (RSSI) and Success Rate

After the **Communication Test** option is clicked, the configuration utility will perform an analysis and then display the results of the test.

The RSSI and Success Rate information can be used to determine the quality of the wireless communication.

RSSI:	77%	78%
Receive/Send:	133	133
Success Rate:	100%	

(4) Improving Wireless Communication

If the communication success rate is not sufficient, the following approach can be used to improve the wireless communication.

- a. The RSSI value is in a generally acceptable range (above 35%)

If the RSSI value is greater than 35%, it means the signal strength is sufficient for data transmission, but the packet error rate is not adequate. This would suggest that there is a level of noise that might be the result of interference from other devices present in the environment. Check whether there is a power system or wireless module, etc. within the vicinity of the RFU-2400 device, as this may be the cause of the interference. The best solution in this situation would be to adjust the RF channel or change the installation location.

- b. The RSSI value is below 35%

If the signal strength is too weak to be received by the remote device, it may cause the communication to become unstable. The following are two methods that are recommended as a solution.

- ✓ Improve the transmission power of the RFU-2400 device

Refer to Section [3.2.2 "Software Configuration"](#) for details of how to achieve a higher RF Power for the RFU-2400 module. Also refer to Section [6.1 "High-gain Antenna"](#) for details of additional high-gain antennas that can be selected.

- ✓ Change the installation location

If obstacles exist in the line of sight (LOS) between the two communication points, refer to Section [6.2 "Extension Cables"](#) for details of extension cables that can be used to adjust the installation location of the antenna.


6 Accessories

6.1 High-gain Antenna

If the transmission distance is too great, the signal strength will become weak, causing interruption to the data transmission. However, a number of high-gain antennas can be used to improve the range and quality of the communication. The following is an overview of each of the antennas available.

(1) ANT-124-05 (Default Antenna)


The ANT-124-05 is the default antenna that is packaged with the RFU-2400. The antenna is omnidirectional and provides a maximum transmission range of 700 meters at a gain of 5 dBi. The specifications below can be used as reference when selecting a suitable high-gain antenna.



Radiation	Omnidirectional
Gain	5 dBi
Polarization	Linear
VSWR	1:1.3 (Max.)
HPBW/horizontal	360°
Impedance	50 Ohms \pm 5 Ohms
Transmission Range	700 m (LOS)


(2) ANT-15

The ANT-15 is an omnidirectional antenna that provides a maximum transmission range of 2000 meters at a gain of 15 dBi.



Radiation	Omnidirectional
Gain	15 dBi
Polarization	Linear
VSWR	1:1.3 (Max.)
HPBW/horizontal	360°
HPBW/vertical	10°
Impedance	50 Ohms ± 5 Ohms
Radome Material	Glass fiber
Transmission Range	2000 m (LOS)
Includes	3S004 x 1 (1 meter long HDF 200 cable with an N-type male to RP-SMA male connector)

➤ Gain Pattern




(3) ANT-18

The ANT-18 is a directional antenna that provides a maximum transmission range of 2500 meters at a gain of 18 dBi.



Radiation	Directional
Gain	18 dBi
Polarization	Linear
VSWR	1:1.5 (Max.)
HPBW/horizontal	15°
HPBW/vertical	15°
Impedance	50 Ohms ±5 Ohms
Radome Material	PC and ABS
Transmission Range	2500 m (LOS)
Includes	3S004 x 1 (1 meter long HDF 200 cable with an N-type male to RP-SMA male connector)

➤ Gain Pattern



6.2 Extension Cable

When the RFU-2400 is installed in an enclosed environment, is shielded, or is within a confined field, it is recommended that an extension cable be used to improve the installation. This combination ensures that the antenna can be positioned outside of any enclosure and helps to maintain the line of sight so that any obstacles can be overcome, which is very important in the implementation of wireless communication. However, by adding an extension cable, it should be noted that the transmission range will be reduced. The actual reduction depends on the length of the cable. The following is an overview of the different lengths of extension cable that are available, together with details of their limitations.



3S001-1



3S003-1



3S005-1



3S008-1

Model	Description	Transmission Range
3S001-1	RG58A/U 1 m cable with RP-SMA male to RP-SMA Female connector	90% of Original Range
3S003-1	RG58A/U 3 m cable with RP-SMA male to RP-SMA Female connector	72% of Original Range
3S005-1	RG58A/U 5 m cable with RP-SMA male to RP-SMA Female connector	59% of Original Range
3S008-1	RG58A/U 8 m cable with RP-SMA male to RP-SMA Female connector	43% of Original Range

Note: Cable attenuation loss = 0.85~1.0 dB/meter @ 2.4-2.5 GHz

➤ Example

The typical maximum LOS transmission range for the RFU-2400 module using the default antenna is 700 meters. If an extension cable is used, the communication range will be reduced by the percentages indicated in the table above, as follows:

- ✓ If the 3S001-1 cable (1 m) is used, the communication range will be less than 630 meters (i.e., 90%).
- ✓ If the 3S003-1 cable (3 m) is used, the communication range will be less than 504 meters (i.e., 72%).
- ✓ If the 3S005-1 cable (4 m) is used, the communication range will be less than 413 meters (i.e., 59%).
- ✓ If the 3S008-1 cable (5 m) is used, the communication range will be less than 301 meters (i.e., 43%).